



USER MANUAL



INOVATION 2

Utility Software for DAT 400 and DAT 500



Pavone Sistemi
pesatura elettronica industriale

TABLE OF CONTENTS

WARNINGS.....	Page	2
INTRODUCTION	Page	3
INSTALLATION	Page	3
OPERATION.....	Page	4
SET-UP	Page	7
CALIBRATION.....	Page	7
PARAMETERS	Page	8
INPUT / OUTPUT	Page	8
COMMUNICATIONS	Page	9
ANALOG.....	Page	10
FUNCTIONS	Page	11
GRAPHIC OF THE WEIGHT	Page	11
BACKUP AND RESTORE	Page	12
HARDWARE TEST	Page	13
DATASHEET AND MANUALS	Page	13
DATA LOGGER	Page	14

WARNINGS

READ this manual BEFORE using the utility software.

FOLLOW these instructions carefully.

SAVE this manual for future use.



CAUTION

The installation and maintenance of this software must be allowed to qualified personnel only.

Be careful when you perform inspections, testing and adjustment with the instrument switched on.

Not observing these precautions, you may be tampering with the operation of the plant where it is connected.

DO NOT allow untrained personnel to work, or tamper with the instrument configurations in which the software is online.

INTRODUCTION

This utility software is used to read and program, in local or remote, data of the DAT 400 and 500 transmitters via the serial or USB connection.

The software works with all PCs equipped with Windows XP or higher and release version 13081 and 13082 on DAT transmitters.

The main functions of the software allow you to:

- Make the set-up of the transmitters
- Calibrate the transmitters
- Testing the inputs and logic outputs and the analog output
- Acquiring weight values by exporting to CSV
- Back up the data by saving them in a file on PC
- Restore previously data saved on PC

INSTALLATION


The installation file is normally provided in a compressed folder both on electronic format and in the CD containing the technical documentation delivered with the transmitters.

Extract all files in the folder Inovation2. Double click on the Setup file to start the installation program. At the end you will open a folder with the USB drivers, install them.


It 'is important that the MANUAL folder is kept in the same file location on SETUP, to allow to the INOVATION 2 software to retrieve manuals on DOCUMENTATION menu.

OPERATION

Start the program on the PC, turn on the instrument, connect the USB port to the PC and put the DAT in REMOTE programming the corresponding parameter in the sub-SERIAL menu, or by moving the jumper next to the USB port in the position shown in the drawing.



This is the basic screenshot of the program where you can find a drop down menu with the main functions, the basic information of the instrument and the actual weight.



Drop down menu:

Language: Select the preferred language of the program (English or Italian).

Connect: Select the connection mode with the transmitter; USB, RS232 or in Offline Mode to use the program without an instrument connected.

Help: Open this document.

Exit: Exit the program.

Under the weight indication there are 3 possible selections of the weight: GROSS, NET and PEAK. To the right there is a button change the function depending on the weight chosen selection.

In GROSS enables the ZERO key (note: you can make a reset of maximum 20 divisions!)

In NET enables TARA key

In PEAK enables the RESET key

On the lower part of the window are the status LEDs of the inputs and outputs.

If the main screen shows the OFFLINE message, it means that there is no communication between the PC and the instrument.

In this case, go to the CONNECT menu, select SEARCH, set the correct port and click the SEARCH button.




When the device is detected, it will appear the channel number, press the button and the DAT will be automatically connected.

The main screen also allows to access the full menu of INOVATION 2 when we move the cursor on the weight indication.


The main menus are:

SETUP, DOCUMENTS, TEST and LOGGER.




A status bar at the bottom allows to know the status of the instrument and the changed data.


This bar appears when the instrument is waiting for data and all changed data were stored in the instrument.



This message appears when there was a communication with the instrument and there has been a positive response.




This message appears when it was attempted writing a parameter outside the allowed values.



This message appears when you have changed a parameter in the instrument and it has been acquired but not saved permanently. To store the data permanently click on the Red bar.



This message appears when the instrument has not responded to the change request, the application automatically retries the writing.




INSTRUMENT SETUP

Pressing the SETUP button you enter the configuration of the instrument, it will appear at first the calibration.


For details on the programmable parameters of the instrument refer to the technical manual.

During the procedures the selection buttons will be replaced by the following panel where you can view the operation main values.



CALIBRATION

In the following screen you can set the weight data as the main capacity and sensitivity of the load cells, you can choose the division value and perform the calibration.



Set the instrument according to the specifications of the system and press SEND to confirm; A confirmation message will appear, accept.

For calibration there are 3 buttons:

ZERO = unloaded system press to make the calibration of Zero.

ACQUIRE = Enter in the box "WEIGHT" the weight value loaded on the system and press the key to perform the FS calibration.

RESET CALIBRATION = Cancel the last calibrated performed.

NOTE: At the end of each procedure press the status bar at the bottom of the window to save the new parameters in the permanent memory of the transmitter.

PARAMETERS

In this menu you can set the parameters of the weight filter and check online via the graphical display the weight trend.

Press **Send** after choosing the desired parameters and save by clicking on the status bar below.



INPUT / OUTPUT

Set all the parameters for the logic outputs. Press **Send** and save by pressing the status bar below.

Home Calib. Param **In/Out** Comm Analog Function Weight Backup

In / Out

OUT 1

Value: 1000.0
Mode: Net
Type: N. Closed
Stable: Stable
Signal: Positive
Hysteresis: 2.0
Timer: 0.0
Delay: 1.0

OUT 2

Value: 8520.0
Mode: Gross
Type: N. Open
Stable: Normal
Signal: Positive
Hysteresis: 0.0
Timer: 0.0
Delay: 0.0

Send

Status:Ready Data saved successfully

SERIAL

Set the parameters related to COM1, RS232 or RS485, and COM 2 when present the FIELDBUS.

Press **Send** to confirm the new values.

NOTE: At the end of each procedure press the status bar at the bottom of the window to save the settings. The parameters are acquired but if not saved they will be lost when you restart the instrument.

Inovation2 - COM3:19200 N,8,1 - Rev.1.0.3

Language Connect Help Exit

Home

Calib.

Param

In/Out

Comm

Analog

Function

Weight

Backup

Communications

RS232/RS485-RS422

Address

2

Response time:

0.01

Protocol

Slave

Frame Data

N-8-1

Baud Rate

19200

Send

Network Parameters

Protocol COM2

PROFINET

IP:

192 · 168 · 0 · 20

SUBNET:

255 · 255 · 255 · 0


Send

Status:Ready

Data saved successfully


ANALOG OUTPUT

In this menu you select the operating mode of the analogue output when present.




Pressing Ctrl + K keys it appears hidden menu for the adjustment of the analog output. Adjust with the arrows Zero and Full Scale of the analog output. To hide the menu again press Ctrl + K keys, or press **Exit**.

NOTE: At the end of each procedure press the status bar at the bottom of the window to save the settings. The parameters are acquired but if not saved they will be lost when you restart the instrument.




FUNCTIONS

Menu for choosing the background color of the application. Pressing **Reset Default** it returns to the default settings



WEIGHT CHART

Graphical weight display; useful for check automatic procedures or operating parameters.



BACKUP AND RESTORE

Menu for saving and / or restoring data previously saved in a PC file.

Press **Backup** to store data on a PC; it will open the classic Windows message "save as", select the destination and the file name.


To **Restore** press the button and select a configuration file previously saved.

Warning: When you make a "RESTORE", all parameters are written in the instrument, so if you just want to display a configuration file on the screen, disconnect the instrument and work in Offline mode.

FACTORY RESET

Procedure protected by password, to be requested to the customer service. The password allows to reset the transmitter to the factory values.


WARNING: all the data set, including calibrations, will be lost. Make a backup before doing this procedure.



HARDWARE TEST


Test menu of the transmitter.

You can simulate the analog output via the percentage bar, open and close the outputs and view the inputs status.



MANUALS AND DATASHEETS

Pressing the DOCU key you can access the page display of the manual and the configuration file (if present).



DATA LOGGER

In this screen you can set a data logger from the PC, it can be used to capture data of an application and then check them in the laboratory.

You can select three types of the logger acquisitions:

MANUAL, TIME and N ° LOG.

Manual: The operation of the START and STOP is handled manually by pressing the buttons.

Time: You set the number of seconds you want to get data

N ° Log: Set the No. of log to be acquired.

To start the data logger it is necessary to enter a value in seconds in the “**Log interval**” to determine each every seconds you want to gain the weight. Select the type of acquisition Manual, Time or No. Log, enter the amount of Log or Total time.

Now press the **Browse** key to enter the name of the file and its destination and press START.

The logger will save a .csv file with date, time and measured value.

The screenshot displays the 'Innovation2 - COM3:19200 N,8,1 - Rev.1.0.3' window. The top status bar includes 'Language', 'Connect', 'Help', and 'Exit' menus. The main interface features a top navigation bar with 'Home', 'Net', and 'NET' buttons. A large digital display shows '430.5'. To the right, input/output status is shown with green and grey circles, and a table of device specifications: Firmware: Progr.81 Rel.0.1, Full Scale: 3960.0, Fieldbus: NONE, Theor. Analogic: 10.83 mA, and Address: 2. The 'Data Logger' section contains fields for 'Log Interval (Sec.):' (1.0), 'Number of Logs' (dropdown), 'Number of logs' (1000), and 'Numbers of log: 0'. It also includes 'START' and 'STOP' buttons. A file path 'C:\Users\Laboratorio\Desktop\prova.csv' is entered in a text field, with a 'Browse' button next to it. The bottom status bar shows 'Status:Ready' and 'Data saved successfully'.

Input:	Output:	Fieldbus:	Theor. Analogic:
1	1	NONE	10.83 mA

Firmware:	Full Scale:	Fieldbus:	Theor. Analogic:	Address:
Progr.81 Rel.0.1	3960.0	NONE	10.83 mA	2

Data Logger

Log Interval (Sec.): 1.0

Number of Logs: [dropdown]

Number of logs: 1000

Numbers of log: 0

C:\Users\Laboratorio\Desktop\prova.csv

START STOP Browse

Status:Ready Data saved successfully



Pavone Sistemi
pesatura elettronica industriale

Certifications:



Via dei Chiosi, 18 - 20873 Cavenago Brianza (MB) ITALIA - Telephone: 02 95339165 (6 lines) - Fax: 02 9501252
E-mail: pavone@pavonesistemi.it